

Parts List for FC96EC Type 0

Item Number	Part Number	Description	Qty Required
1	9R195169	GUARD KIT	1
2	9R195170	GUARD ATTACH. KIT	1
3	9R195171	CLINCHER POST KIT	1
4	9R195172	PEDDLE SWITCH KIT	1
5	9R193715	COVER,BACK	1
6	9R195173	FOOT GUARD	1
7	9R193717	TORSION SPRING	1
8	9R193718	TORSION SPRING	1
9	9R195174	RETURN SPRING KIT	1
10	9R193720	LEFT ARM	1
11	9R193721	RIGHT ARM	1
12	9R193722	OUTER SPACING RING	1
13	9R193723	BLOCK	1
14	9R193724	INNER SPACING RING	1
15	9R193725	STAPLE HEAD LINK	1
17	9R193727	STAPLER HEAD	1
18	9R193728	POSITIONING PLATE	1
19	9R193729	POSITIONING BLOCK	1
20	9R193730	FLAT SPRING	1
21	9R193731	SPACER	1
22	9R193732	OUTER PLATE	1
23	9R193733	INNER PLATE	1
24	9R193734	LEFT SIDE	1
25	9R193735	RIGHT SIDE	1
26	9R193736	STAPLE BELT GUIDE	1
27	9R193737	STAPLE GUIDE	1
28	9R193738	WOOL FELT	1

Parts List for FC96EC Type 0

Item Number	Part Number	Description	Qty Required
29	9R193739	SHAFT	1
30	9R193740	SHAFT BUSHING	1
31	9R193741	PIVOT BUSHING	1
32	9R193742	NAIL RAIL CHASSIS	1
33	9R195175	FOOT PAD KIT	1
34	9R195176	SWITCH KIT	1
35	9R193745	COMPRESSION SPRING	2
36	9R193746	GUIDE BLOCK SPRING	1
37	9R193747	NAIL GUIDE PLATE	1
38	9R193748	POSITIONING BLOCK	1
39	9R193749	PUSH NAIL BLOCK B	1
40	9R193750	PUSH NAIL BLOCK C	1
41	9R193751	ANVIL BASE	1
42	9R193752	FEEDER GUIDE	1
43	9R193753	PUSH NAIL BLOCK A	1
44	9R193754	FEEDER PUSHER	1
45	9R193755	DRIVER GUIDE	1
46	9R193756	COVER PLATE	1
47	9R193757	RIGHT BRACKET	1
48	9R193758	LEFT BRACKET	1
49	9R193759	PUSH NAIL SHAFT	1
50	9R193760	CLINCHER	1
51	9R193761	FIXED CLINCHER PLATE	1
52	9R193762	ADJUSTMENT SCREW	1
53	9R193763	CLINCHER BASE	1
54	9R193764	PIVOT BOLT	2
55	9R195177	CLUTCH KIT	1

Parts List for FC96EC Type 0

Item Number	Part Number	Description	Qty Required
57	9R193767	SHAFT PIN	1
58	9R193768	SHAFT PIN	1
59	9R193769	UPPER CLINCHER POST	1
60	9R193770	LOWER CLINCHER POST	1
61	9R193771	SWITCH PLATE	1
62	9R193772	PEDAL SPRING	1
63	9R195178	ROD END KIT	1
64	9R193774	FOOT PEDAL	1
65	9R193775	INNER PEDAL	1
66	9R193776	SHAFT	1
67	9R193777	SHAFT SLEEVE	2
68	9R193778	SHAFT	1
69	9R193779	BASE MIX	1
70	9R195179	CONTROLLER BRKT KIT	1
71	9R193781	BASE SUPPORT	1
72	9R193782	COVER PLATE	1
73	9R193783	BOLT,STOP	1
74	9R193784	SIDE COVER	1
75	9R193785	TRANSMISSION ROD	1
76	9R195180	CONTROLLER KIT	1
77	9R193787	NAIL TRACK	1
78	9R193788	SPACER RING	2
79	9R195161	MOTOR KIT	1
80	9R193790	WASHER	2
81	9R193791	PUSHER SPRING	1
82	9R195162	COVER ASSY	1
83	9R193906	PIN KIT	1

Parts List for FC96EC Type 0

Item Number	Part Number	Description	Qty Required
85	9R193907	HEAD ASSEMBLY	1
86	9R193908	SWITCH KIT	1
87	9R193798	POSITIONING BLOCK	1
89	9R193800	FIXED PLATE	1
90	9R193801	SIDE COVER	1
91	9R193802	DRIVER GUIDE BRACKET	1
93	9R193804	SWITCH COVER	1
96	9R193807	COVER PLATE	1
97	9R193808	WRENCH RACK	1
98	9R193809	SHAFT SLEEVE	1
99	9R193810	TORSION SHAFT	1
100	9R193811	SENSOR BRACKET	1
101	9R193812	ADJUSTABLE PLATE	1
102	9R193744	NAIL FRAME	1
103	9R193743	NAIL FRAME SHAFT	2
105	9R193765	PLATE,GUIDE	1
503	9R193815	SHCS CAP SCREW	2
504	9R193816	SPRING WASHER	1
508	9R193820	SHCS CAP SCREW	10
509	9R193821	SHCS CAP SCREW	4
513	9R193825	HEX NUT	1
514	9R193826	REDUCER	1
517	9R193830	SHCS CAP SCREW	4
518	9R193831	FLAT WASHER	4
519	9R193832	SPRING PIN	2
520	9R193833	SHCS CAP SCREW	4
523	9R193836	SELF LOCK NUT	1

Parts List for FC96EC Type 0

Item Number	Part Number	Description	Qty Required
526	9R193839	SHCS CAP SCREW	7
527	9R193840	RETAINER RING	2
528	9R193841	RETAINER RING	1
529	9R193842	FLAT WASHER	1
530	9R193843	HEX HEAD BOLT	1
531	9R193844	FLAT WASHER	1
532	9R193845	SHCS CAP SCREW	1
533	9R193846	LOCK WASHER	1
534	9R193847	SPRING PIN	1
537	9R193850	HEX NUT	2
538	9R193851	SET SCREW	1
539	9R193852	SHCS CAP SCREW	1
540	9R193853	CAP SCREW	2
541	9R193854	SELF LOCK NUT	1
542	9R193855	SHCS CAP SCREW	2
543	9R193856	SHCS CAP SCREW	1
544	9R193857	CAP SCREW	2
545	9R193858	SPRING PIN	4
546	9R193859	SHCS CAP SCREW	1
547	9R193860	FLAT WASHER	1
548	9R193861	SHCS CAP SCREW	2
549	9R193862	SPRING PIN	1
550	9R193863	CAP SCREW	2
551	9R193864	CAP SCREW	4
552	9R193865	SHCS CAP SCREW	1
553	9R193866	SPRING POST	1
554	9R193867	PIN SPRING	4

Parts List for FC96EC Type 0

Item Number	Part Number	Description	Qty Required
555	9R193868	HEX HEAD BOLT	1
556	9R193869	FLAT WASHER	1
557	9R193870	SPRING WASHER	1
558	9R193871	SELF LOCK NUT	1
559	9R193872	RETAINER RING	3
560	9R193873	SELF LOCK NUT	1
561	9R193874	FLAT WASHER	1
562	9R193875	CAP SCREW	5
563	9R193876	SHCS CAP SCREW	1
564	9R193877	SELF LOCK NUT	2
565	9R193878	SELF LOCK NUT	2
566	9R193879	LOCK WASHER	1
567	9R193880	SHCS CAP SCREW	1
568	9R193881	CAP SCREW	2
569	9R193882	HEX NUT	1
570	9R193883	FLAT WASHER	1
571	9R193884	SHCS CAP SCREW	1
572	9R193885	HEX NUT	1
573	9R193886	SPRING TIP	2
574	9R193887	SPRING WASHER	1
575	9R193888	SHCS CAP SCREW	1
576	9R193889	CAP SCREW	4
577	9R193890	HEX NUT	1
578	9R193891	SHCS CAP SCREW	4
579	9R193892	SHCS CAP SCREW	1
580	9R193893	HARNESS BUSHING	2
584	9R193897	SHCS CAP SCREW	2

Parts List for FC96EC Type 0

Item Number	Part Number	Description	Qty Required
585	9R193898	ROUND CROSS SCREW	2
586	9R193899	SENSOR	1
591	9R193904	HARNESS FITTING	1
592	9R193905	SHCS CAP SCREW	1
598	9R193911	HEX HEAD BOLT	1
599	9R193912	SPRING WASHER	1
602	9R193915	HEX NUT	1
603	9R193917	POWER CORD	1
604	9R193918	SWITCH HARNESS	1
605	9R193921	MOTOR HARNESS	1
608	9R193924	HARNESS FITTING	1
609	9R193925	HARNESS FITTING	3
610	9R193926	SHCS CAP SCREW	2
613	9R193929	SHCS CAP SCREW	1
616	9R195156	NYLON SWITCH TUBE	1
617	9R195157	NYLON MOTOR TUBE	1
618	9R195158	NYL MIC. SWITCH TUBE	1
619	9R195159	NYLON SENSOR TUBE	1
620	9R195160	NYLON CLUTCH TUBE	1
623	9R195163	CABLE GLAND	1
624	9R195167	NYLON WAVE TUBE	1
625	9R195168	BHCS CAP SCREW	2
626	9R195164	SHOCK LABEL	1
627	9R195165	WARNING LABEL	1
628	9R195166	IDENT. LABEL	1