



HCMS-S-32
HCMS-S-35
HCMS-S-36

No.	Part#	Description	Q'ty	Remark
001	A07300101	LINK 1	2	
002	A07304901	NUT	1	
003	A07402701	TUBE	2	
004	A07400901@	LINK 2 UNIT	2	
005	A07402201	SPACER	2	
006	A07401001	DRIVER SEAT	1	
007	HCMB-S-P1	BODY SET	1	HCMB
007	HCMS-S-P1	BODY SET	1	HCMS
008	A07401901	DRIVER	1	32
008	A07800501	DRIVER	1	35
008	A08900501	DRIVER	1	36
008	A08200701	DRIVER	1	7437,9040
009	A00603402	TUBE	2	
010	HCAB-S-32-P2	MAGAZINE UNIT	1	32
010	HCAB-S-35-P2	MAGAZINE UNIT	1	35
010	HCAB-S-36-P2	MAGAZINE UNIT	1	36
010	HCAB-S-7437-P2	MAGAZINE UNIT	1	7437,9040
011	A07400701	BRACKET	1	
012	A00103903@	RIGHT PUSHER GUIDE	1	
013	A00103904@	LEFT PUSHER GUIDE	1	
014	A00103501	ROLLER	1	
015	A00103710@	PUSHER SET	1	32
015	A00103709@	PUSHER SET	1	35
015	A03100601@	PUSHER SET	1	36
015	A00103714@	PUSHER SET	1	7437
015	A00103715@	PUSHER SET	1	9040
016	A00607101	NUT	2	
017	A00103203	ROD	2	
018	A07403001	SPRING	1	
019	A07400801	BRACKET	1	
020	A07305901	SHAFT STOPPER	1	
021	A08400101	TUBE	1	
022	A07402401	TUBE	2	
023	A07305001	SPACER 3	2	
024	A07305101	DISHING WASHER	2	
025	A07303501	SPACER 6	2	
026	A08400201	TUBE	2	
027	A07300201	LINK 2	2	
028	A07300301	LINK 3	2	
029	A07304401	SPACER 2	4	
030	A00603503@	LINK 4 UNIT	1	
031	A07303901	BALANCER	1	
032	A07304101@	STEP BOARD SET	1	
033	A07401101	SPRING	2	
034	A07402501	WASHER	1	
035	A07401801	BRACKET	1	
036	A07401501	GUIDE/BLADE R.	1	32
036	A07800601	GUIDE/BLADE R.	1	35
036	A08900601	GUIDE/BLADE R.	1	36
036	A08200501	GUIDE/BLADE R.	1	7437

No.	Part#	Description	Q'ty	Remark
036	A08300101	GUIDE/BLADE R.	1	9040
037	A07401601	GUIDE/BLADE L.	1	32
037	A07800701	GUIDE/BLADE L.	1	35
037	A08900701	GUIDE/BLADE L.	1	36
037	A08200601	GUIDE/BLADE L.	1	7437
037	A08300201	GUIDE/BLADE L.	1	9040
038	A07403301	SHAFT	1	32,7437
038	A07801001	SHAFT	1	35,9040
038	A08900801	SHAFT	1	36
039	A07401401	FRONT PLATE	1	
040	A07401201@	BRACKET SET	1	
041	A07303801	SPACER 1	2	
042	A07402101	MOLD	1	32
042	A07800801	MOLD	1	35,36
042	A08200801	MOLD	1	7437,9040
043	A00603801	SPRING	1	
044	A07303301	TUBE	2	
045	A07303401	SPACER 5	2	
046	A07304001	BRACKET	1	
047	A07305301	SPACER 4	2	
048	A07402301	SHAFT A	1	
049	A07800401	PLATE/REAR	1	35
049	A08900401	PLATE/REAR	1	36
049	A08200401	PLATE/REAR	1	7437,9040
501	BAJ0106	SNAP PIN	2	φ 6
502	BAE04071	WASHER	2	φ 7
503	BAD04081	LOCK NUT	3	M8x1.25
504	BAA080060	SPRING PIN	2	φ 8*60
505	BAC0808161	HEX.HD.BLOT	2	M8x1.25-16
506	BAC0404252	HEX.SOC.HD.BOLT	2	M4x0.7-25
507	BAD01041	LOCK NUT	2	M4
508	BAC0206162	HEX.SOC.FLAT COUNTER SUNK HD. SCREW	2	M6x1-16
509	BAC0308202	HEX.SOC.HEADLESS SCREW	1	M8x1.25-20
510	BAA040016	SPRING PIN	1	φ 4*16
511	BAC04081102	HEX.SOC.HD.BOLT	1	M8x1.25-110
512	BAC04081002	HEX.SOC.HD.BOLT	1	M8x1.25-100
513	BAE04081	WASHER	3	φ 8
514	BAC0808351	HEX.HD.BLOT	2	M8x1.25-35
515	BAE01081	SPRING WASHER	2	φ 8
516	BAC04081402	HEX.SOC.HD.BOLT	1	M8x1.25-140
517	BAD01081	LOCK NUT	2	M8
519	BAC0608162	HEX.SOC.HD.BOLT	2	M8x1.25-16
520	BAE04081	WASHER	2	φ 8
521	BAC0408252	HEX.SOC.HD.BOLT	2	M8x1.25-25
522	BAC0404162	HEX.SOC.HD.BOLT	1	M4x0.7-16
523	BAA040012	SPRING PIN	4	φ 4*12
524	BAC0405162	HEX.SOC.HD.BOLT	2	M5x0.8-16
525	BAC0308122	HEX.SOC.HEADLESS SCREW	1	M8x1.25-12

No.	Part#	Description	Q' ty	Remark
526	BAD01051	LOCK NUT	4	M5
527	BAC0405202	HEX.SOC.HD.BOLT	2	M5x0.8-20
528	BAD01041	LOCK NUT	1	M4
529	BAE04081	WASHER	6	φ 8
530	BAC0408252	HEX.SOC.HD.BOLT	2	M8x1.25-25
531	BAC0204202	HEX.SOC.FLAT COUNTER SUNK HD. SCREW	1	M4x0.7-20
532	BAD01041	LOCK NUT	1	M4x0.7